



## Bluetooth Setup for eBeam Edge™

### Mac OS X 10.6

---

These instructions will help you set up your Bluetooth-enabled eBeam Edge on a Mac OS X 10.6.

Before you begin, make sure that you have the latest eBeam software installed on your computer.

- Plug your eBeam receiver into a power outlet, and confirm that the light is glowing blue.
- If you have an iMac, Mac Mini or Mac Pro system, you will need to plug in a USB mouse before proceeding to the next step to ensure you have mouse control until Bluetooth devices are connected. For MacBook, MacBook Pro and MacBook Air systems continue to the next step.
- Plug in the eBeam Bluetooth dongle.
- To connect an eBeam device, go to **System Preferences > Bluetooth** and click on the + button to add a device.
- Select eBeam device from the list of Bluetooth devices.
- When prompted enter the pairing code **1234**.
- A dialog will be shown if the pairing is successful, and the glowing light on your eBeam receiver will flash four times. This flashing verifies that your computer has made a connection with the Bluetooth receiver. .
- To connect a wireless keyboard or mouse through the eBeam Bluetooth dongle, go to **System Preferences > Bluetooth** and click on the plus button to add a device. After adding a wireless mouse you no longer need to use a USB mouse.